



BALLAST PAVERS ON TABS AT INNER FACE OF PARAPET; SEE ROOF PLAN FOR LAYOUT

DISK ANCHORS
 FOR USE WITH INSTAGREEN CARPET OR GARDMAT AND PLUGS
 SEE DETAILS WSD-CB-1 THROUGH WSD-CB-4 FOR DISK ANCHOR SPACING REQUIREMENTS.

ROOF PENETRATION
 DRAIN STRUCTURE, DAVIT, EQUIPMENT SUPPORT, CURB, ETC.

CHECKER BLOCK® UNITS TO BE CUT
 CUTS SHALL BE MADE WITH MASONRY SAW TO CREATE CLEAN CUT THROUGH UNIT AND INTERNAL REINFORCING. BREAKING UNITS SHALL NOT BE ACCEPTED AND SHALL BE REJECTED.
 CUT FACES SHALL BE COATED WITH TWO (2) COATS OF OIL BASED PRIMER PAINT BEFORE FINAL INSTALLATION.

STAINLESS STEEL ZIP-TIES
 AVAILABLE FROM HYDROTECH
 CONNECT ALL CHECKER BLOCK® UNITS TOGETHER IN EACH DIRECTION.



GARDEN ROOF ASSEMBLY

AMERICAN HYDROTECH, INC.

CHECKER BLOCK® INSTALLATION CUTTING GUIDELINES

SCALE: NONE
 DATE: 11/01/17

GB-7

This information is intended only for general conceptual purposes. It is based on data and knowledge considered to be true and correct. It is offered for the user's consideration, investigation and verification and is not intended to substitute for the advice provided by appropriate professionals. Hydrotech assumes no liability for the use of this information. The determination of the suitability and applicability of this information is the sole responsibility of the user.